

# AIR SUMP PUMP(MULTI)

## Eliminate all water residues and sludge perfectly before Painting !!

### • Specification

Model	AIR SUMP PUMP(MULTI)
Code	A66000
Power supply	Air Pressure
Pump Weight(Kgs)	2.6
Valid length of outlet hose(M)	20
Max output(L/min)	100
Water pressure(Kgf/cm <sup>2</sup> )	3.6
Max RPM/min	12000

#### Included

- Air Sump Pump(2.6kgs) for larges
- Ejector(10m)(3.4kgs) for residues
- Air Rotor Lub Oil(250ml)

\* This has been used in most of shipyards to improve their painting job.

### Solution

[before]



[after]





# AIR SUMP PUMP (MULTI)

## • Attention

- This is available only for water level under Air Vent.
- Prior to working, to be lubricated Air-Inlet with "Air Rotor Lub Oil".
- Disconnect certainly to be "OFF" air inlet line on cleaning.
- After working, it is recommendable to lubricate Air-Inlet with "Air Rotor Lub Oil" for efficient maintenance.




Air Sump Pump / Air Rotor Lub Oil



Ejector (10m)

## • Air Sump Pump for Larges



## • Ejector for Residues

